



User Manual

CAM-NS2-RT

**OEM Reverse Camera Retention Interface
For Nissan Colombia Vehicles**

APPLICATION:

Nissan

Note (Colombia) 2015>

Frontier (Colombia) 2015>

DISCLAIMER:

Prior to Installation

Read the manual prior to installation. Technical knowledge is necessary for installation. The place of installation must be free of moisture and away from heat sources. Please ensure you use the correct tools to avoid damage to the vehicle or product.

Connects2 can not be held responsible for the installation of this product.

Technical Support

Connects2 want to provide a fast and suitable resolution should you encounter any technical issues. With this in mind, when contacting Connects2, try to provide as much information as possible. This will speed up the process and help us to help you.

Please use our dedicated online technical support centre: support.connects2.com

- OEM Camera Retention Interface
- Instructions

INSTALLATION

1. Connect the yellow RCA connector from the interface to the camera input on the rear of the aftermarket head unit
2. Connect the white connector from the interface to the vehicle harness
3. Connect the Purple/White flying wire to the vehicle's Reverse Signal feed



Subscribe to our YouTube Channel for installation guides and tips... www.youtube.com/connects2