



Porsche(PCM4.0-2017~2019) WIRING DIAGRAM ---LDS-PCM40-CP




DIP SWITCH SETTING

(After changing the dip code,press "reset"or power-on again)

PIN	Setting	Description
PIN 1	OFF/ON	NG / NG
PIN 2	OFF/ON	NG / Touch point coordinate correction,and then turn on"OFF"
PIN 3	OFF/ON	Close front view camera/Open front view camera
PIN 4	OFF/ON	Reversing gridline/Enable 360 panoramic
PIN 5	OFF/ON	NG / NG
PIN 6	OFF/ON	Rear view camera CVBS input / RGB input
PIN 7	OFF/ON	NG / NG
PIN 8	OFF/ON	Aftermarket rear view camera/Original rear view camera



REMARK:Please keep in the AUX interface when switch the CarPlay interface



AUX Connector
Pls plug it into the original AUX IN port



- 1) Long press and hold "NAV" button to switch MENU, long press"NAV" button again,exit the switch MENU.
- 2)Other functions use touch screen to control it.