


# HP301

## German Engineering. Out of the ordinary.



#### **Precautions**

- Contains small parts which may be a choking hazard. Not suitable for children under age 3.
- When unplugging the headphones never pull on the cable. Always grasp and pull the connector.
- Loud music may cause hearing damage. It is best to avoid high volume levels when using headphones, especially for extended periods.
- Use caution when using your headphones while operating a vehicle or engaging in any activity that requires your full attention. Check and follow local laws regarding mobile phone and headphones use.
- Warning signals, such as a siren, can sound different by wearing headphones. Be aware of how these sounds may vary in character so you can recognize them as needed.
- Do not drop, sit on, or allow the headphones to become wet.
- This product contains magnetic material.

### **Environmental Reference**

- Old electronic devices don't belong into the bin.
- If you want to dispose this equipment later, remove all cables and send it back to Ampire.
- You can dispose this device together with your old car, too. You don't have to remove it in this case.
- The packing can be recycled. Dispose the packing in a collecting system planned for it.



Two batteries (AAA) must be placed into the battery compartment of the headphones and ensuring that the positive and negative terminal of the batteries are insert correctly.

## **Using the wireless Headphones**

- Slide the power and channel switch of the headphones to the position A/B to power on the headphones. The Ppower and channel indicator turns to red when the power and channel switch slides to A and turns to green when the power and channel switch slides to B. You can enjoy different music or movie with different channel selection.
- 2. Adjust the volume of the headphones with the Volume control knob to desire listening level.
- 3. You can silence the music to listen outside by pressing the **monitor button** continuously and releasing the **monitor button** to listen to the sound of the headphones playing again.
- 4. Slide the **power switch** of the headphones to position **OFF** to power off the headphones when it is not in use for a long time.
- 5. Connect audio source and **Audio input jack** of the headphones with audio connect line, the headphones are also used as regular wired stereo headphones without battery.
- 6. You can rotate the earcups 90° and the fold-flat earcups increases portability and ease of storage.


## **Special Features**

- <u>The headphones have auto mute function</u>: When the IR transmitter turns off or the headphones do not receive the IR signal, the headphones automatically turn off their power amplifier and mutes.
- <u>The headphones have auto power off function</u>: After 3 - 5 minutes if the headphones do not receive the IR signal, the headphones will automatically turn off their power and the power indicator turns off.
- 3. Fold-flat earcups:

The fold-flat earcups increase portability and ease of storage.

#### **Headphones Features:**

- (1) + (3) Infrared Light Sensor
  - (2) Battery Compartment Cover
  - (4) Power and Channel Switch
  - (5) Power and Channel Indicator
  - (6) Volume Control Knob
  - (7) Monitor Button
  - (8) Audio Input Jack for wired Headphones



#### 4 System: HP30 Infrared light 7 **Carrier Frequency:** Channel A Left: 2.3 MHz Right: 2.8 MHz 5 Channel B 8 Left: 3.2 MHz Right:3.8 MHz Modulation: FM Stereo S/N: >=60dB Channel Separation: >=40dB Distortion: <1% Frequency Response: 30 – 20,000 Hz Power Supply: 2 x R3 AAA (Not included in scope of delivery)

#### **Technical Specifications**

4





Langwadener Straße 60 D-41516 Grevenbroich Email: info@ampire.de

Technical Support: Phone: 02181-81955-0 Email: support@ampire.de

#### www.ampire.de