

## MOTIP Engine Oil Stop Leak

Ord.-no.: 090613

### Technical Information



Stop leakage of engine oil in the car with MOTIP Engine Oil Stop Leak. This additive stops oil leaking from the engine oil system in the car. In addition, the additive keeps the engine gaskets soft and supple.

#### Quality & properties

- Reduction of oil loss
- Improved reliability of operation
- Increased engine performance
- Less wear and tear

#### Physical & chemical data

- Colourname: Transparent
- Vapour pressure: <0,1/50 bar
- Flash point: 72 °C
- Content: 300 ML

#### How to use

- Before use, carefully read the directions on the packaging and act accordingly.
- Check engine oil level before application.
- Add to the engine oil. One can (300 ml) sufficient to treat 5 liters of engine oil. For larger volumes add 50 ml of Engine Oil Stop Leak per liter of engine oil. Works during operation.
- We recommend cleaning the oil system with Engine Oil Flush before application.

#### Environmentally sound

European Aerosols is committed to apply formulations without restricted or critical ingredients and to achieve best possible performance. The caps and packagings are made of recyclable material.

#### Disposal

Only the completely emptied cans should be put into the recycling skip or appropriate container for reclaimable refuse. Cans which are not empty should be disposed off as "special refuse".

#### Marking/Labeling

All products made by European Aerosols comply with the actual labelling regulations according to Preparation Guideline 1999/45/EG. All aerosols correspond to TRGS 200 and TRG 300 as well as to aerosol guideline 75/324/EWG in the actually valid version.

For any further technical questions call our hotline +31 (0) 561 69 44 00 from Monday to Thursday from 9 h a.m. to 3 h p.m. or on Friday until 12 h p.m.

**As of November 29, 2021** – This release replaces all eventually earlier issued versions.